

The QRPro System is designed for rapid mount and dismount of Joysticks, Throttles, Gearsticks and Brakelevers to and from your rig

Note: you will need a QRPro Base Plate to use this adapter.

Attaching the QRPro Thrustmaster Warthog Throttle Kit

Before attaching the QRPro Kit

- 1. Flip over the Thrustmaster Warthog Throttle so you can see the base.
- 2. Unscrew the 5 Phillips No.2 Screws as shown by the red arrows
- 3. Remove the Table Mount base plate (with the pads) to expose the Rig Mount base plate. Note: You can optionally remove the added weights from the Rig Mount base plate at this point to make it lighter if you so wish.





4. Reattach the Rig Mount base plate to the assembly carefully making sure that the earth tag remains under one of the screw holes.

Attaching the QRPro Kit

- 5. The QRPro Thrustmaster Warthog Throttle Kit comprises a QR Plate and an Adapter Plate fixed together to be QR mounted from the left, but if you require a different orientation, now is a good time to reorientate the adapter plate on the QR Plate by removing the 4x M6 countersunk screws and repositioning before retightening to 1.5nm (just to the pinch, do not over tighten and metal fixing when attaching to plastic parts)
- 6. The QRPro Thrustmaster Warthog Throttle Kit has 4x M6 Tapped holes (one in each corner) push the supplied M6 cap head Allen screws with washers through the Throttle assembly and screw in to the QRPro Thrustmaster Warthog Throttle Adapter plate, again avoiding overtightening.
 - 7. Enjoy!

If you require further support, please used the <u>contact form on our website</u>, or email us directly <u>support@qr4rigs.com</u>, we will be more than happy to help you.