



Quick Release Mounts for Sim Rigs

QR4rigs®


Change your rig in seconds, spend more time in the game!

The QRPro System is designed for rapid mount and dismount of Joysticks to and from your rig

Note: you will need a QRPro Base Plate to use this adapter.

Fitting the QRPro Plate to your Turtle Beach VelocityOne™ Flight Stick

- Flip over the joystick so you can see the underside of the baseplate.
- Locate the 3x M5 tapped holes (circled in red)



- The QRPro Turtle Beach VelocityOne™ QR Plate kit comes in 2 pieces. The QR Plate and the Adapter Plate.

- The Adapter Plate (shown left) needs to be fitted first.

- Using the 3x M5x14mm screws provided, attach the Adapter Plate (shown Left) to the VelocityOne™ Flight Stick.

- Tighten to the pinch.

- The standard orientation of the QRPro QR Plate is for the Joystick to mounted to your rig from rear towards the front
- It is possible to rotate the QR Plate and fit to the Adapter Plate in 90 degree increments if a different orientation is required.
- Secure the QRPro QR Plate to the Adapter Plate with the provided 4x M6x14mm screws.
- Tighten to the pinch + 1/8th Turn more.



DO NOT OVERTIGHTEN ANY OF THE SCREWS or you may damage the plastic plates.

If you require further support, please use the [contact form on our website](#), or email us directly support@qr4rigs.com, we will be more than happy to help you.