



Quick Release Mounts for Sim Rigs

QR4rigs®

Change your rig in seconds, spend more time in the game!

The QRPro System is designed for rapid mount and dismount of Joysticks to and from your rig

Note: you will need a QRPro Base Plate to use this adapter.


Fitting the QRPro Plate to your Thrustmaster Warthog Joystick

- Flip over the joystick so you can see the underside of the baseplate (the large square plate at the bottom in the picture)
- Unscrew the 4 screws located underneath the joystick's metal base plate, and remove the metal base plate.

Read more: [Download Official Manual](#)



- Use the 4 screw threads located on the underside of the joystick to attach the joystick directly to your QRPro Plate with the 4 screws provided in the orientation that suits the QRBase Mount plate as it is mounted on your rig. Tighten to the pinch.



If you require further support, please use the [contact form on our website](#), or email us directly support@qr4rigs.com, we will be more than happy to help you.