



**Quick Release Mounts for Sim Rigs**


**QR4rigs®**

*Change your rig in seconds, spend more time in the game!*

**The QRPro System is designed for rapid mount/dismount of controllers on your rig!**

**Note: you will need a QRPro Base Mount to use this adapter.**

### Fitting the QRPro Thrustmaster Viper TQS Quick Release Plate Kit




- Flip over your Thrustmaster Viper TQS
- For a more solid fit, it is advisable to remove the 4 rubber pads from the bottom of the unit and will prevent the Adapter Plate warping under tension. This can be done by gently heating the rubber pads with a hairdryer or heat gun on a low setting to soften the adhesive and peeling them off carefully.
- Locate the fixing holes on the underside of the Thrustmaster Viper TQS highlighted here in **RED**.

- Note the orientation of the QR Plate in the picture on the right.

- The QRPro system is design for controllers to be mounted directionally from the rear to the front of the rig.



- If you wish to mount from the front to the rear: remove the four M6x14mm screws holding the QR plate to the Adapter Plate (shown in **GREEN** on the right) then rotate the plate 180° and replace the M6x14mm screws and tighten to the pinch.



- Secure the QRPro Thrustmaster Viper TQS Quick Release Plate assembly to the underside of the Thrustmaster Viper TQS with the five M6x18mm Screws provided in the kit into the 5 holes
- Tighten to the pinch then 1/16<sup>th</sup> turn.

**Do NOT overtighten any of the screws.**

If you require further support, please use the [contact form on our website](#), or email us directly [support@qr4rigs.com](mailto:support@qr4rigs.com), we will be more than happy to help you.